	Set hot water valvaes back to the running position.
	Make sure that the anode is back in the hot water heater.
	Fill the water tank to 1/3.
	Dilute 1/2 a cup of bleach and add to the fresh water tank.
	Fill tank to capacity.
	Turn water pump on.
	Run the water on all the lines.
	Run the water on the toilet but do not let the bleach water sit to protect the seal.
	Add fresh water to the toilet bowl.
	Leave the bleach water in the lines and tank for at least 6 hours.
	Check the water line connections to make sure they are tight.
	Run the water 1 more time through all the lines.
	Turn off water pump.
	Dump the fresh water tank.
	Fill the fresh water tank with fresh water.
	Turn water pump on.
	Run the water on all the lines.
	Turn off water pump.
	Dump the fresh water tank.
	Connect water to city connector.
	Run the water on all the lines.
	Dump gray water tank