	Turn on all the faucets to drain the system.
	Open the low point drains
	Drain the fresh water tank.
	Pop the safety valve on the hot water heater to get rid of pressure.
	Take the anode rod out of the hot water heater.
	Put the low point drains back on.
	Remove the matress from the bed.
	Remove plywood from the bed.
	Turn off all the faucets.
	Turn the hot water heater valves into the bypass position.
	Put the antifreeze hose into the antifreeze container.
	Open the valve for the antifreeze hose.
	Turn on the water pump.
	Wait for the system to pressuarize
	Run the cold water on the kitchen sink until pink comes out.
	Run the hot water on the kitchen sink until pink comes out.
	Run the cold water on the bathroom sink until pink comes out.
	Run the hot water on the bathroom sink until pink comes out.
	Run water through the shower head until pink comes out.
	Flush the toilet until pink comes out. Leave some pink in bowl to protect the seal.
	Turn water pump off.
	Close the valve for the antifreeze hose.
	Remove the antifreeze hose from the antifreeze container.
	Pour some antifreeze in the trap in the kitchen sink.
	Pour some antifreeze in the trap in the bathroom sink.
	Pour some antifreeze in the trap in the shower.
	Remove the screen from the city water inlet and push the button inside to release the pressure.
	Put the plywood back on the bed.
	Put the matress back on the bed.
	Flush the hot water heater.
	Put the anode rod back in the water heater.